

## **G3 COMETH configuration guide (v1.2)**

Revision log:

v1.2>update for fw6.4.1 sqlite\_db

v1.1>support for slave device echo

>specify respond string must be terminated by char <LF>

Filename :	iotasset.txt
Location :	\user

### 1. Introduction

The file 'iotasset.txt' contains the assets configuration that is required by the COMETH program to acquire data from simple serial or Ethernet devices. Acquired data is then inserted into database for downstream IoT clients.

### 2. IOT asset 'KEY,VALUE' general format

Each IOT asset is defined by using a BLOCK of 'key, value' pairs (CSV format). There are four COMETH key names that must be present for each IOT asset.

<b>COMETH KEYS</b>	<b>Description</b>
<b>TYPE</b>	Define the type of COMETH communication
<b>ADDR</b>	Define the address of the COMETH slave device
<b>SEND</b>	Define the COMETH command string for query device
<b>RECV</b>	Define the COMETH response echo and data type

Each asset block must include the pair 'Key, Field\_name' for database purpose. Backslash (\) and double quote mark (") char cannot be used. Comments can be inserted by using the hash (#) sign.

To ease parsing of different types of assets, the asset blocks need to be located between the start and end of block markers.

<b>COMETH BLOCK MARKER</b>	<b>Description</b>
COMETH_START	Define the start of COMETH assets
COMETH_STOP	Define the end(stop) of COMETH assets

### 3. IOT asset 'KEY,VALUE' setup information

#### **TYPE**, m [, i]

Argument	Value	Description
m	SER	Simple SERIAL data (RS-232/RS-485 selectable)
	TCP	Simple TCP socket (Ethernet)
	UDP	Simple UDP socket (Ethernet)
	DIN	Digital INPUT
	DIP	DIP switch
i	1, 2, 3, 4, 5,....	Poll interval for each asset. #1

#1 Optional: Argument [i] if excluded will result in default polling i=1, which polls on every interval.

Example of Poll Interval calculations with master Poll Period = 15 sec.  
note: Poll Period is the time interval between polling, refer to web config 'IoT Hardware'.

Asset Poll Period	Calculation	Poll Interval (i)
1min	1*60/15	4
30min	30*60/15	120
1 hour	1*60*60/15	240
3 hour	3*60*60/15	720

#### **ADDR**, n0

#### DIP

#### **ADDR**, n1.n2.n3.n4 : p

#### TCP/UDP

Argument	Value	Description	Notes
n0	1-4	DIP number	For DIP switch select
n1.n2.n3.n4:p	n1,n2,n3,n4=0-255 p=0-65535	Device IP address Device port	For TCP/UDP socket

#### **SEND**, s, t

Argument	Value	Description
s	string of characters	Command to send eg "LAUNCH"
t	LF	End char = <LF>
	CRLF	End char = <CR><LF>

**RECV**, u, v [, x, y]

Argument	Value	Description
u	Echo from slave device	E1=echo filter on, E0=echo filter off
v	Data Type	Data type in respond string
x	Multiplier	Value = Value*Multiplier + Adder #3
y	Adder	Value = Value*Multiplier + Adder #3

#3 Optional: for Data Type DECIMAL, **both** x & y arguments required when applied.

**Slave device's respond string must be terminated by char <LF> (ASCII 010 or 0x0A).**

**Non-decimal chars will be removed from the respond string.**

#### 4. Data Type definitions

##### **DATA TYPE BOOLEAN**

v [Data Type]	Description
BOOL	Boolean value, ie 0 or 1

##### **DATA TYPE DECIMAL**

v [Data Type]	Description
DEC	Decimal number eg 96.51, 10.1, 2000

#### 5. Example for IOT asset configuration

#iotasset example for SERIAL, TCP, UDP, DIN and DIP

```
COMETH_START          #start of COMETH block

TYPE, SER              #Serial device
ADDR, 0                #address not use in serial
SEND, TEMP, LF        #send message "TEMP<LF>"
RECV, E1, DEC         #echo filter on, respond message eg "29.5<LF>"
Key, Temperature

TYPE, TCP              #Ethernet device (TCP socket)
ADDR, 192.168.1.101:70 #Device IP=192.168.1.101, Port=70
SEND, WIND, LF        #send message "WIND<LF>"
RECV, E1, DEC         #echo filter on, respond message eg "15.7<LF>"
Key, WindSpeed
```

```

TYPE, UDP                                #Ethernet device (UDP socket)
ADDR, 192.168.1.105:77                   #Device IP=192.168.1.105, Port=77
SEND, HUMI, LF                            #send message "HUMI<LF>"
RECV, E0, DEC                             #echo filter off, respond message eg "75<LF>"
Key, Humidity

TYPE, DIN, 10                             #Digital Input, poll on every 10 polling interval
ADDR, 0                                   #fields not in use given 0 value
SEND, 0
RECV, 0, BOOL
Key, Alarm

TYPE, DIP, 10                             #DIP switch, poll on every 10 polling interval
ADDR, 1                                   #DIP number 1
SEND, 0                                   #fields not in use given 0 value
RECV, 0, BOOL
Key, RunMode

COMETH _STOP                             #end of COMETH block

```

#### 6. Methods to upload 'iotasset.txt' file to G3

-Upload the iotasset.txt file from your computer using the 'Upload iotasset.txt' button in the 'IoT Hardware' tab.

-Put the iotasset.txt file in \user folder of USB drive (with label 'FATBOX'). Plug the USB drive into G3 and click the 'Upload to FATBOX' button in the 'Management' tab.

-Use SCP/Putty console or WinSCP.

<EOF>